

Tricks of the Trade: Particle Mounting Methods

Walter C. McCrone, McCrone Research Institute

Those of us who have particle identification problems sometimes have very small samples, say, only a few nanograms - even less sometimes. We also like to make up permanent Aroclor 5442 preparations of these tiny samples for safe keeping and future reference. If we mount such small samples in a normal drop of Aroclor filling an 18 mm diameter coverslip, we may spend a few frustrating minutes looking for the sample in a few acres of Aroclor.

My solution is to use a very tiny Aroclor droplet under a small coverslip. Ten millimeter or smaller round coverslips are available from Erie Scientific in Portsmouth, New Hampshire. To obtain a suitable Aroclor droplet (Figure 1), I keep my Aroclor-filled canada balsam bottle nearly empty (2-3 mm deep) on my hotplate at 98° C and with a fine-tipped glass rod permanently therein. I place my clean microscope slide with a centrally Sharpie pen-marked "q" on the under surface on the hotplate. Ten seconds later, I remove the glass rod and tick the tip wet with Aroclor to the circle of "p" on the other side of the slide. I then place a clean 10 cm round coverslip on this drop (no sample), heat it to 100° C, and press on the coverslip to thin the Aroclor. It then cools to room temperature as I walk to the refrigerator with the prep and a razor blade. After 10 seconds for the slide on the cold freezer compartment surface, I remove the slide and flick off the coverslip with the razor under one edge. Now, back to the stereo microscope where I use a No. 2 or 3 tungsten needle to place the sample at the center of the Aroclor circle and replace the coverslip (Figure 2). Now, another 10 seconds on the hotplate followed by removal to a heat insulating Post-It pad and quick use of a coverslip gripper-particle crusher and disperser (i.e., a pencil eraser). I disperse the sample into single

particles in a small area at the center of the Aroclor preparation. After circling its expanse on top of the coverslip (Figure 3) I am ready to find and examine the particle(s) by PLM.

Once in a great while, I then find I cannot identify one of the important components of this Aroclor preparation by size, shape, color, refractive indices, and birefringence. I must then get one of the biggest of those particles out, cleaned off and remounted in a different liquid or for SEM/EDS or FTIR/microscopy. This I do, starting with circling the chosen particle location on top of the coverslip. I then invert the slide and trace the particle circle on the bottom of the slide. Then back to the freezer to flick off the coverslip.

A fine-tipped tungsten needle, then draws a square through the Aroclor and around the particle. With the same needle working under a small drop of water over the particle on top of the Aroclor, I spear the square of Aroclor (and particle) and bring it out through the water drop surface to a clean slide. The Aroclor is removed using a drawn-out polyethylene pipette filled with amyl acetate leaving a clean particle. A small droplet placed near the particle is drawn by a nearly flat No. 2 needle tip over the particle, hesitating a few seconds for the Aroclor to dissolve and then continuing on to move the amyl acetate droplet plus Aroclor away from the particle. Several airborne trips back to the particle and drawing more droplets away usually leaves a clean particle in less than 30 seconds total time. Needless to say, this operation takes place under the stereo at times 40-50.

The dry particle is then mounted in a different liquid for PLM, for SEM/EDS on a beryllium stub or in a diamond cell for FTIR/microscopy. ■

ANALOG/DIGITAL PRINTERS



- Seikosha Video Printers**
- 256 Grey Levels
 - 10 MHz - 135 MHz
 - 5¢ - 19¢ - 40¢ Hardcopies
 - 3 x 4, 8 1/2 x 8 or 8 1/2 x 11 Formats



- Mitsubishi Printers**
- Dye-Sublimation Printers
 - Analog/Digital Input
 - 16.7 Million Colors
 - 4 x 4 thru 12 x 18 Format
 - Thermal Greyscale Printers




- Tektronix Printers**
- Dye-Sublimation Printers
 - Digital/Postscript Input
 - 16.7 Million Colors
 - 8 1/2 x 11 Thru 8 1/2 x 14
 - TCP/IP and Ethertalk

VITAL IMAGE TECHNOLOGY INC. OFFERS COMPLETE SALES AND SERVICE, INCLUDING FREE INSTALLATION IN MOST PARTS OF THE UNITED STATES.



VIT

(800) 860-IMAGE



VITAL IMAGE TECHNOLOGY INC.




Figure 1: Droplet of <2 mm Aroclor 5442 on the slide, 25X.




Figure 2: Aroclor droplet plus sample.





Figure 3: Dispersed particles of the sample in a 4 mm² area.

Reprinted from Volume 44:1 10 (1996) of the *MICROSCOPE* from the McCrone Research Institute.

WHEN RESULTS COUNT... APPLY THE TOTAL SOLUTION.

When you need fast, accurate results for your microanalysis applications, count on NORAN Instruments' VOYAGER to deliver the right answer. We offer a full family of software that works together to solve the most challenging EDS, Digital Imaging, and WDS analytical problems. From Intelligent Qual automatic peak identification to our **new** WDS Automation and Analysis, VOYAGER has the total system solution.



Our new WDS application for VOYAGER is powerful, yet easy to use. Our design lets you optimize the analysis setup for single elements, for the best results possible.

Analysis Manager Control
File View Tools
Set Up Procedure Set Up Points
Analyses Control File: (unnamed)

Image Display
File View Acquire Display Process Analyze Tools Schedules

Cell 1
Grey5 Sn Pb Solder Ingot
x: 171 y: 72 i: 178

Cell 2
Grey5 Sn Pb Solder Ingot, BEI
x: 443 y: 308 i: 164


Cell 3
Xray2:SN-L Quant maps
x: 11 y: 12 i: 52

Cell 4
Xray2:PB-M Quant maps
x: 11 y: 12 i: 48

Powerful Analysis Manager software lets you automate your EDS, WDS, Imaging, Feature Sizing, and other laboratory procedures. With fully matrix-corrected quantitative maps, you can easily determine the distribution of element weight percentages in your sample.

WDS Periodic Table
Peak Position (nm): [1] File Table
Peak Search: [Rn]
Dwell Time (s): 0.300
Radius (mm): 2.500
Step Size (mm): 0.10

WDS Control
File View Acquire Spectrometer Analyze Tools Schedules
Measure background: Per element Peak search: Per element
Beam (nA): 29.75 X (mm): 24.721 Y (mm): 24.206 Z (mm): 4
Active Element Status Standard Unknown Uncorrected
Cu_Ka1_spec2_LIF_spectromet Complete 18 20 1.1065
Ni_Ka1_spec1_LIF_co Complete 45 0 0.0110
Fe_La1_spec1_TIP Complete 0 0 0.0000
Ti_Ka1_spec2_BEI Complete 1612 0 0.0000



VOYAGER's Intelligent Qual quickly and accurately identifies spectral peaks, even in tough overlap situations such as Ti-L with N-K, and W-M with Si-K.

**VISIT US
AT MSA '96**



NORAN Instruments Inc., Corporate Headquarters,
2551 West Beltline Highway, Middleton, WI 53562-2697 USA
Tel.: 608 831 6511, Fax: 608 836 7224
Internet: voyager_info@noran.com
World Wide Web: <http://www.noran.com>
NORAN Instruments B.V., Tel.: 31 35 6998888, Fax: 31 35 6949913
NORAN Instruments GmbH, Tel.: 49 7251 97910, Fax: 49 7251 979111
NORAN Instruments Japan, Tel.: 81 3 3298 8451, Fax: 81 3 3298 8441
NORAN Instruments Korea, Tel.: 82 342 708 3091, Fax: 82 342 708 3093
NORAN Instruments U.K., Tel.: 44 1908 696290, Fax: 44 1908 696 292