Highly Active CeO₂ Nanorods Support for CO Oxidation

Randi Dangerfield, Dingqiang Li, and Ruigang Wang*

Department of Chemistry and Materials Science and Engineering Program, Youngstown State University, Youngstown, OH 44555. Email*: rwang01@ysu.edu

The study of metal nanoparticles on oxide supports is of importance in heterogeneous catalysis because the size and nature of the interaction of a metal nanoparticle with an oxide support are critical in determining catalytic activity and selectivity [1-5]. Reduction and oxidation (redox) at elevated temperatures are essential steps for the catalytic reactions. Due to the superior oxygen transport capacity, ceria (CeO₂) with other oxides constitute an important class of catalysts and/or catalyst supports that can exchange oxygen rapidly under variable reducing or oxidizing conditions, mainly accommodated by a reversible valence change (2Ce(IV)O₂ \leftrightarrow Ce₂(III)O₃ + 1/2O₂). In this paper, we report a facile synthesis of CeO₂ nanorods with {200} surfaces by a hydrothermal reaction, and catalytic activity characterization of 1wt% Au/CeO₂ and 1wt% Ni/CeO₂, aiming to understand the support shape effect for low temperature CO oxidation.

CeO₂ nanorods were prepared using a hydrothermal method. Typically 0.1M Ce(NO₃)₃·6H₂O and 6M NaOH mixtures were heated to ~130 °C and held for 48 hrs in a sealed 200 mL Teflon-lined autoclave (~50 % fill). Then the autoclave was cooled to room temperature before the solid products were recovered by suction filtration. The materials were washed thoroughly with distilled water to remove any co-precipitated salts, then washed with ethanol to avoid hard agglomeration in the nanoparticles, and dried in air at 50 °C for 12 hrs. Transmission electron microscopy (TEM) characterization was performed using a JEOL2100 operated at 200 kV and equipped with an EDAX detector and annular dark-field detector. CO temperature programmed reduction (CO-TPR) study was examined using CO chemisorption on the Quantachrome iQ and Micrometrics 2920 to explore how much CO adsorbs as a function of temperature. The catalytic oxidation of CO was conducted by using a fixed bed plug flow reactor system. 1vol%CO/20vol%O₂/79vol%He with a 70 mL/min flow rate was supplied through mass flow controller and passed through the catalyst bed. The catalyst (~100 mg) was mixed with quartz wool (coarse, 9 μm) and filled in the quartz tube reactor. The reaction temperature was programmed between room temperature and 300°C and monitored by thermocouple. The reactant CO and product CO₂ were analyzed by using an on-line gas chromatograph (SRI multiple gas analyzer GC, 8610C chassis) system.

Figure 1 (a) and (b) shows typical low magnification and high resolution TEM images of CeO2 nanorods prepared by a hydrothermal method, respectively. We have used CO temperature programmed reduction (TPR) to measure the CO consumption (2CeO₂+CO→Ce₂O₃+CO₂) during the reduction of CeO₂. Figure 1 (c) shows the CO-TPR profiles of CeO₂ nanorods, 1wt% Au/CeO₂, and 1wt% Ni/CeO₂ under a 5%CO/95%Ar. The two reduction regions for the surface and bulk reductions, respectively, are characteristics of ceria-type redox catalysts, and reduction percentage, reduction temperature and the distribution between the surface and bulk areas are good indicators for the overall performance of the material as an oxidation-reduction catalyst. We will present the correlation study between the CeO₂ nanoparticle size/shape and reactivity as determine by TEM, CO-TPR, and flow reactor test on the catalyst activity of CO oxidation.

References

- [1] Washs, I.E. et al, Catal. Today 27 (1996) 437.
- [2] Datye, A.K. et al, J. Catal. 109 (1988) 76.
- [3] Flytzani-Stephanopoulos, M. et al, Annu. Rev. Chem. Biomol. Eng. 3 (2012) 545.
- [4] Gorte, R.J. AIChE Journal 56 (2010) 1126.
- [5] Cuenya, B.R. Thin Solid Films **518** (2010) 3127.
- [6] The support from the American Chemical Society Petroleum Research Fund (#52323) and Department of Transportation (DoT-CTME project), YSU University Research Council grant and the use of TEM facilities at the Center of Excellence in Materials Science and Engineering at Youngstown State University are gratefully acknowledged.




Figure 1 low magnification (a) and high resolution (b) TEM images of CeO₂ nanorods, and CO-TPR profiles of CeO₂ nanorods, 1wt% Au/CeO₂ and 1wt% Ni/CeO₂ under a 5%CO/95%Ar gas atmosphere.